



# iPhone 4S Rear Panel Replacement

Replace a cracked rear panel on your iPhone 4S.

Written By: Walter Galan



## INTRODUCTION

Remove the rear panel to access the internal components of your iPhone.



### TOOLS:

- [P2 Pentalobe Screwdriver iPhone](#) (1)



### PARTS:

- [iPhone 4S Blank Rear Glass Panel](#) (1)

#### Fix Kit / Black

*This kit contains the part and all tools needed.*

- [iPhone 4S Blank Rear Glass Panel](#) (1)




#### Fix Kit / White

*This kit contains the part and all tools needed.*

- [iPhone 4S Used OEM Rear Glass Panel](#) (1)
- [iPhone 4S Transparent Rear Panel](#) (1)

## Step 1 — Rear Panel



-  Before you begin, discharge your iPhone battery below 25%. A charged lithium-ion battery can catch fire and/or explode if accidentally punctured.
- Power off your iPhone before beginning disassembly.
- Remove the two 3.6 mm Pentalobe P2 screws next to the dock connector.
-  Be sure the driver is well seated when removing Pentalobe screws, they are very easy to strip.
-  During reassembly, we recommend you replace the 5-point screws with equivalent Phillips screws. Our [Liberation Kit](#) provides the tools and screws needed to replace the Pentalobe screws with Phillips screws.

## Step 2



- Push the rear panel toward the top edge of the iPhone.

**i** The panel will move about 2 mm.

## Step 3



- Pull the rear panel away from the back of the iPhone, being careful not to damage the plastic clips attached to the rear panel.
- Remove the rear panel from the iPhone.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-18 10:05:20 PM.